



FIG. 21

ERASE METHOD	
TRANSMISSION OF SOURCE CODE FROM BOOT MAT]T5
EXECUTION OF INITIALIZATION	J- T6
EXECUTION OF REASE	
END	

FIG. 22

INITIALIZATION OF ERASE)	•
SET DATA RELATED TO OPERATION FREQUENCY TO FPEFEQ REGISTER (R4)	T60
SET USER BRANCH ADDRESS TO FUBRA REGISTER (R5)	T61
JUMP SUBROUTINE TO ERASE INITIALIZATION PROGRAM (RAMTOP+32byte)	EXECUTION OF INITIALIZATION PROGRAM
JUDGE WHETHER INITIALIZATION PROGRAM WAS COMPLETED NORMALLY	T63
END	